

## How to use Protect(LockOut) function menu in Maxloader

TMEL AT49BVxx device family has the “LockOut” function.

After LockOut is enabled in a certain block, the protected memory block cannot be Erased or Programmed.

If you cannot program or erase a certain block in maxloader software, the particular block has been Locked.

Once you protect certain memory block, you cannot release the LockOut(protected) block.

However, you can still “erase” and “program” the memory block while “protection Override” is enabling.

-Click on Option button in the Maxloader menu and click on “enable” button in the Protection Override box

- Erase and Program will be functioning after above process is done

Please contact [support@eetools.com](mailto:support@eetools.com) for further questions.

